



**Dovre 250 Cleanburn
Cast Iron Stove**
Installation and Operating Manual
PM150 Issue 1 (May 2005)



Craftsmanship in Cast Iron

Dovre 250 Cleanburn Cast Iron Stove

Installation and Operating Manual

These instructions should be read carefully and saved by the user for future reference.

Contents

Introduction to your Dovre Stove	2
Unpacking your Dovre 250	3
Getting the best from your Dovre 250	3
Location for the installation	4
Assembly	3-4
Installation	4
Chimney Connections	4-5
Operating your Dovre 250	5-7
Servicing and Maintenance	7
Warranty Details	7
Guide to Woodburning	8
Troubleshooting	8

Introduction to your new Dovre 250

We would like to thank you for purchasing a Dovre stove and trust that it will provide you with many years of useful service.

At Dovre we have been producing cast iron stoves for over 60 years and we strive to ensure that our products meet with the highest level of performance, efficiency, safety and quality. So much so that we guarantee all Dovre body castings for 5 years.

Owning a stove might be a new experience for you. Therefore, to ensure that you get the best performance from your new Dovre, do please take a little time to read through this manual.

The 250CB is a specially designed stove for burning wood and most smokeless fuels. It is essential that when wood is used, it is well seasoned for a minimum 2 years and has a maximum moisture content of 20%. If unseasoned wood is used, heat outputs will not be obtained and serious damage will occur in the chimney and flueways.

The dimensions of your new stove are illustrated in Fig 1. Be careful to ensure that your fireplace is going to accept the appliance and that you have allowed for at least 300mm (12") of hearth space in front of the stove.

WE RECOMMEND THAT YOUR DOVRE IS FITTED BY AN EXPERIENCED INSTALLER ACCUSTOMED TO THE INSTALLATION OF SOLID FUEL BURNING APPLIANCES.

If you are unsure about any aspect of the installation or operation procedures, your Dovre dealer will be pleased to help.

It is important that the Installation is carried out in compliance with current Building Regulations.




Fig 1 - STOVE DIMENSIONS

Width	Height	Depth	Weight	Heat output	Flue diameter
455mm	550mm	405mm	79kg	6kW	125mm

SAFETY

A fireguard is not provided with this stove. However, it is recommended that one compliant with BS 6539 or BS 6778 is fitted, particularly if the stove is to be used in the presence of young children, the elderly and infirm.

Unpacking your Dovre 250

Your Dovre 250 is constructed from high-grade quality cast iron and is therefore not light in weight. We recommend that 2 people are available to handle the stove.

Care should be taken not to break the glass whilst handling the appliance.

Before taking your Dovre to its installation location, remove the stove from its outer packing and timber pallet. Stand the stove in the upright position, protecting carpets or other floor coverings with rigid cardboard. The stove carton is ideal for this purpose.

Locate the small green quality control slip and retain for future reference.

Getting the best from your Dovre 250

There are 3 golden rules to follow:

1. USE GOOD FUEL - NEVER BURN UNSEASONED OR DAMP WOOD
2. YOU MUST HAVE A GOOD CHIMNEY DRAUGHT - NEVER USE YOUR DOVRE STOVE WITH A POOR CHIMNEY
3. AVOID OPERATING THE STOVE FOR LONG PERIODS ON CONTINUOUS LOW TEMPERATURE

USING SMOKELESS FUELS

Your Dovre 250 is capable of burning a wide variety of smokeless fuels but the availability of different fuels varies from area to area. Seek advice from your local fuel merchant and try out different fuels by buying in small quantities until you find the fuel best suited to your Dovre.

THE USE OF BITUMINOUS COAL AND PETROLEUM BASED FUELS IS PROHIBITED.




Fig 2 - STOVE COMPONENTS

Location for Installation

The location in which your stove is to be installed will of course depend on the chimney available. If you do not have a chimney, there are a number of prefabricated flue systems available and your Dovre dealer will be pleased to offer guidance on the subject.

Building Regulations must be observed when considering the location of your Dovre 250. More precise information can be found later in this manual but it is important to ensure that a suitable hearth, complying with Building Regulations, is available.

NEVER ALLOW A MECHANICAL AIR EXTRACTOR TO BE USED IN THE ROOM OR ADJOINING ROOMS AS THIS COULD CAUSE THE APPLIANCE TO EMIT SMOKE INTO THE ROOM.

Assembly

FITTING THE FLUE CONNECTOR

If your Dovre 250 is to be connected to the chimney via the top flue connector, proceed as follows:

- Apply a thin and even coat of fire cement to the flanges on the flue spigot and the circular flue blanking plate.
- Attach the flue spigot to the top opening in the stove, using the 2 nuts and bolts (M8 x 25CSK slotted) supplied.
- Attach the circular flue blanking plate to the rear opening of the stove using the retaining bar and (M6 x 25) bolt supplied.
- Ensure that both flue spigot and blanking plate are securely tightened and correctly sealed with the fire cement.

If your Dovre 250 is to be connected to the chimney via the rear flue connector, proceed as follows.

- Apply a thin and even coat of fire cement to the flanges on the flue spigot and the circular flue blanking plate.
- Attach the flue spigot to the rear opening in the stove, using the 2 nuts and bolts (M8 x 25CSK slotted) supplied.
- Attach the circular flue blanking plate to the top opening of the stove using the retaining bar and (M6 x 25) bolt supplied.
- Ensure that both flue spigot and blanking plate are securely tightened and correctly sealed with the fire cement.

Installation

HEARTH & CLEARANCE REQUIREMENTS

INSTALLATION AGAINST A WALL

For installation as a free standing unit e.g. against a wall. (See Fig 3).

The minimum constructional hearth required is 840mm (33") x 840mm (33") and the unit must not be placed less than 150mm (6") from the back and sides of the hearth. The wall must be constructed from non-combustible materials and must be a minimum height of 1200mm (48"). The required wall thickness will depend on the distance between the back of the stove and the wall (A). If this distance is less than 50mm (2"), the wall should be at least 200mm (8") thick. If the distance from the back of the stove to the wall is between 50mm (2") and 150mm (6"), the wall thickness must be at least 75mm (3") thick. If single wall flue pipe is attached to the appliance, the pipe should be a minimum of three times its diameter from any combustible materials.

INSTALLATION IN A FIREPLACE RECESS

For installation in an fireplace recess or inglenook:

The distance the hearth must protrude in front of the appliance should be a minimum of 300mm (12").

The minimum thickness of hearth (B) should be 125mm (5") and this may include the thickness of a concrete floor including hearth tiles. If a hearth is constructed and / or supported on timber, the timber should be at least 250mm (10") away from the top surface of the hearth.

If a timber mantel is installed, the distance from the stove body and / or any single skin flue pipe, if attached to the top of the stove, to the mantel must be a minimum of 450mm (18").




Fig 3.

Chimney Connections

CONNECTION FROM THE TOP OF THE APPLIANCE

A non-combustible register plate should be fitted to the lower section of the chimney. (See Fig 4).

125 mm diameter 316 grade 1mm thick stainless steel flue pipe or vitreous enamel pipe suitable for use with solid fuel appliances should be used to connect the top spigot of the stove to the chimney or chimney liner. (See Fig 4). All connecting joints must be female pointing up and joints should be properly sealed with fire cement. If the chimney is not immediately above the stove, off set bends of either 30 degree or 15 degree angles may be used. (See Fig 5). Try to avoid long runs of pipe that are not vertical.

CONNECTION FROM THE REAR OF THE APPLIANCE

A non-combustible register plate should be fitted to the lower section of the chimney. (See Fig 6).

150 mm diameter 316 grade 1mm thick stainless steel flue pipe or vitreous enamel pipe suitable for use with solid fuel appliances should be used to connect the rear spigot of the stove to the chimney or chimney liner. All connecting joints must be female pointing up and joints should be properly sealed with fire cement. If the chimney is not immediately above the stove, off set bends of either 30 degree or 15 degree angles may be used. Try to avoid long runs of pipe that are not vertical. Start by connecting a 90-degree or 45 degree "T" section to the flue spigot at the rear of the stove.

NEVER INSTALL HORIZONTAL PIPE RUNS OVER 150mm (6") DIRECTLY OFF THE BACK OF THE STOVE.




Fig 4.

The Chimney

ACCESS FOR SWEEPING CHIMNEY

The chimney should be checked and swept at least once a year and it is important to allow provision for gaining access to the chimney. On masonry chimneys, a standard soot door, obtainable from your Dovre dealer, can be used. On other factory made chimneys, it is important to ensure an access cleaning door is provided. It is advisable to ensure that the connecting flue pipe to the chimney has an access door fitted. An access door close to the appliance will also facilitate the use of a chimney vacuum cleaner to ensure clean appliance maintenance.

AIR SUPPLY

Your Dovre 250 requires an air supply to the room. The air vent should have a minimum air flow area of 110 sq.cm (17 sq inches).

THE CHIMNEY

(Minimum height requirement 4.5 metres (16 ft.)

This is one of the most important aspects of the installation of your Dovre stove. It is important to ensure the following.

CHIMNEY DRAUGHT

Draught Requirement 1.5 to 2mm Wg.

Too much draught will cause excessive heat outputs and fuel consumption. Inadequate draught may cause smoke emission to the room and poor combustion resulting in a build up of tar and creosote deposits on the glass, inside walls of the appliance and the chimney.

For existing chimneys, always ensure that the chimney is checked and swept prior to the installation taking place.

MASONRY CHIMNEYS

The chimney must be sound, in good condition and must not be shared with another appliance. In the event of the chimney being unlined, it is advisable to have a survey carried out to check for the presence of leakage and other defects.

Lining the chimney with a suitable 150mm (6") diameter liner for wood burning and solid fuel burning applications, will improve the performance and efficiency of the stove.

THE ADVANTAGES OF A LINED CHIMNEY

- With most unlined chimneys, the cross-section of the chimney is excessive as in the case of large old inglenook fireplaces. Because of the large volume of cold air in large chimneys, it is difficult for the flue gases to rise easily through the chimney. This causes the unburned volatile in the smoke to adhere to the chimney walls.
- The inner surfaces of some unlined chimneys are rough with jagged edges causing difficulties in obtaining a good draught.
- Unlined chimneys are often defective with cracks leaking fumes into other parts of the house.
- Larger, unlined chimneys, being cold, encourage the formation of tars (wood smoke condensation), which can penetrate the walls of the chimney leaving unpleasant black stains on internal plastered walls.

PREFABRICATED CHIMNEY SYSTEMS

If a masonry chimney is not available, there are a number of proprietary brand prefabricated flue systems available. Your Dovre Dealer will be pleased to offer information and advise on this subject.

CHIMNEY TERMINAL

Down draught problems may be experienced if the top of the chimney is close to adjacent taller trees and / or buildings. Your Dovre Dealer will be pleased to advise on suitable anti down draught cowls should these conditions prevail.

Provided that your Dovre 250 stove has been installed in accordance with the above installation procedures, you should now be ready to 'light up'. (See page 6 to light your Dovre 250).




Fig 4.




Fig 5.

Operating your Dovre 250

If your Dovre 250 is finished in enamel, care should be taken to avoid knocks as the enamel surface could “chip”.

Non-enamelled Dovre stoves have been treated with a high temperature resistant protective paint, which produces an odour when the stove is new. We recommend that you leave a window open during the first few hours of use while the paint is curing.

CONTROLLING YOUR DOVRE 250

WOODBURNING

There are two fundamental air controls on your Dovre 250, the lower spin wheel air control and the top lever air control.

When using your Dovre as a woodburner, the top air control should be generally left in the fully open position. If the top air control is left for long periods in the closed position, the air wash system will not function and the glass will quickly discolour. The lower air control should only be opened when first lighting or re-fuelling with wood.

Choose well seasoned hardwood logs 300mm (12”) in length and no greater than 75mm-100mm (3” to 4”) in diameter, and a minimum of two years old.

REMEMBER: THE DRYER THE WOOD THE BETTER

WET UNSEASONED WOOD PRODUCES CREOSOTE AND TAR IN THE CHIMNEY AND CAUSES RAPID BLACKENING OF THE GLASS DOOR.

SMOKELESS FUEL BURNING

When using your Dovre for burning smokeless fuel, the top air control should always be closed (lever pushed fully to the right) a couple of minutes after re-fuelling. The lower air control should be opened when first lighting or re-fuelling with solid fuel. The heat output and burning rate of solid fuel only is regulated by opening and closing the lower air control.

TO LIGHT YOUR DOVRE 250

- Open the lower air control wheel.
- If burning wood, open the top air vent fully by sliding the lever to the left. **(NOTE THE TOP AIR VENT SHOULD MOSTLY BE CLOSED WHEN BURNING SMOKELESS SOLID FUEL).**
- Lay rolled up newspapers and small sections of wood (kindling wood) on the grate. Light the paper with a long taper. If kindling wood is not available, firelighters may be used with small pieces of split wood laid on top of the firelighters.
- Close the door but do not fully lock at this stage. The fire should now start to burn fiercely and brightly. If this does not happen, check for chimney blockage.

As soon as the wood is burning with a well-established heat, add 2 or 3 logs or a small quantity of smokeless fuel and close the door tightly.

After a further couple of minutes, if using wood, fully close the lower air control and if using solid fuel, close the lower air control to the almost fully closed position. For solid fuel burning, the lower air control is used to control the burning rate of the fuel. (See left “Controlling your Dovre 250”).

REMEMBER: FOR WOODBURNING - OPERATE YOUR DOVRE WITH THE BOTTOM AIR CONTROL CLOSED.

CONTROL THE BURNING RATE BY ADJUSTING THE TOP AIR CONTROL.

FOR SMOKELESS FUEL BURNING - OPERATE YOUR DOVRE WITH THE TOP AIR CONTROL MOSTLY CLOSED. CONTROL THE BURNING RATE BY ADJUSTING THE LOWER AIR CONTROL.

Note: Try to avoid operating your Dovre 250 with the lower air control fully open for long periods of time. Operating your stove in this manner causes the stove to burn excessive amounts of fuel and could lead to premature wear on the grates, fire bricks and baffle plate.

OVERNIGHT BURNING

WOOD BURNING

Before retiring to bed:

- Ensure that there is a good hot base to your fire and fully load the fire with hardwood logs, ideally 300mm (12”) long with a maximum diameter of 100mm (4”).
- Open the lower and upper air controls to allow the fire to burn fiercely. After 2 or 3 minutes, close the lower air control fully and close the upper air control to the “almost” fully closed position.

If you require your stove to be used the following morning, carry out the following procedure:

- Open the lower and upper air controls.
- Using a poker, lightly rake the ashes in the stove, bringing any hot embers to the centre of the grate.

- Place small sections of wood on the grate and close the stove door to the “almost” closed position.
- When the fire becomes established, add more fully and proceed as above (See page 6 “To light your Dovre 250”).

SMOKELESS FUEL BURNING

Before retiring to bed:

- Empty the ashtray.
- Load the firebox with smokeless fuel. Do not over-load. The top of the fuel bed should be below the front fuel retainer.
- Fully open the lower control. After 2 or 3 minutes, close the lower air control fully. Ensure that the top air control is fully closed.

If you require your stove to be used the following morning, carry out the following procedure:

- Open the lower air control.
- Empty the ash tray.
- Load the firebox with smokeless fuel. Do not over-load. The top of the fuel bed should be below the front fuel retainer.
- Close the door securely and close the lower air control to the required position.

Care and Maintenance

CAUTION: IF THE APPLIANCE EMITS SMOKE INTO YOUR ROOM, IT IS NOT THE FAULT OF THE APPLIANCE. THERE WILL EITHER BE A STRUCTURAL FAULT OR DESIGN FAULT IN THE CHIMNEY OR LACK OF VENTILATION IN THE ROOM.

NEVER LET THE ASHPAN OVERFILL

There should always be a good air space between the top of the ashpan and the underside of the grate. Failure to do this will cause premature deterioration of the grate and will make it difficult to empty the ashpan. Your Dovre 250MFR is equipped with a special grate mechanism which allows ashes to be riddled into the ashpan whilst the stove door is closed. The riddling control lever is situated on the left-hand side of the front of the stove above the ashpan door. Gently move the lever backwards and forwards to clear the grate of ash.

To remove the ashpan open the door and carefully remove the ashpan using the handle tool provided. Ashes must be disposed of carefully and it is a good idea to purchase a Stovax Ash Caddy.

After replacing the empty ashpan in the ashpan compartment, ensure the ashpan door is fully closed.

DAILY MAINTENANCE

- Empty the ash pan
- Check and clean light stains from the glass. Wipe the door glass clean using a cloth and Stovax Glass Cleaner.

WEEKLY MAINTENANCE

- The fibre door gaskets around the inside edge of the doors provide an air tight seal. Check these regularly and remove any ash or wood particles gently with a soft brush.

ANNUAL MAINTENANCE

At the end of the heating season, thoroughly clean the inside of the stove and adjoining flue pipe.

Arrange for your chimney sweep to inspect and clean the chimney.

Carry out the following checks and procedures:

- Replace the door and glass gaskets
- Check and replace any worn fire bricks as necessary
- Check and replace the cast iron grate if necessary
- Check, clean and replace the top baffle plate if necessary

STOVE BODY

To clean enamelled surfaces use a soft dry cloth. For painted surfaces, the stove body can be repainted or touched up using Stovax Thermolac stove paint.

GLASS

You may notice a build up of deposits on your glass, particularly if the stove has been used for long periods at low temperatures. A hot brisk fire will normally cure this problem, but if the problem persists, check the quality of your wood and/or chimney. It is always recommended to fire your stove hard after an overnight burn. From time to time, the glass can be cleaned using Stovax stove glass cleaner. Never use abrasive pads, or clean the glass when hot.

Managing your wood supplies

If you are buying wood from a log merchant, try to ensure that the wood has been seasoned for at least 2 years. 3 years is even better. The wood should preferably be cut to lengths of 300mm (12") and split to a width of between 50mm and 100mm (2"- 4").

Store the wood under cover to protect from rain but ideally the wood should be stored in a place where the wind will be allowed to freely ventilate the sack.

Try to obtain hardwoods such as oak, elm, beech or ash. These woods will provide more calorific value per cubic metre than softwoods.

Trouble Shooting

SMOKE EMISSION

If smoke occurs when the stove door is opened, it is a sign that the flue draught is inadequate. Mostly, burning unseasoned wood causes this condition and it usually indicates that the combustion temperatures are too low. To overcome a weak draught, ensure your wood is dry and build a hot fire, leaving both air controls in the fully open position. If the problem persists, arrange for your chimney to be expertly checked for design and construction faults. In some instances, down draught conditions will exist and it may be necessary to fit an anti down draught device to the top of the chimney.

FIRE DOES NOT BURN FOR LONG PERIODS

Wood can contain a number of variable factors related to species, weight, age and moisture content. It is therefore difficult to be precise with regards to the length of burn time.

If it is thought that the fuel is burning too quickly:-

- The diameter of the logs is too small.
- If softwoods are used, change to using hardwoods.
- Excessive chimney draught. If so, fit a draught stabiliser.
- Worn out door and glass seals need replacing.

Always try to avoid running your stove for long periods of time with the air controls closed. This point is particularly important if the wood is not well seasoned. Failure to do so, will cause the glass, stove walls, and chimney to become soiled with tar deposits.

Five Year Warranty

If the castings on this appliance should prove to be defective within five years of the purchase date, the faulty castings will be replaced free of charge, subject to the following conditions:

- 1) The purchaser shall complete the registration card enclosed and return it within seven days of purchase. Failure to return the registration card could result in delays in processing any claims.
- 2) The appliance shall have been installed in compliance with the installation instructions and current Building Regulations.
- 3) The appliance shall not have been used for the burning of unseasoned wood and/or prohibited fuels.
- 4) This warranty only applies to the appliance body castings and does not include renewable components including grates, ashpans, and glass, seals, baffle plates and chips on enamel castings.
- 5) This warranty does not cover site visits and any claims should be notified to your dealer.

This warranty does not affect your Statutory Rights.

United Kingdom and Eire distributors for Dovre:

STOVAX

Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, England, EX2 7LF.

Telephone: (01392) 474011 Fax: (01392) 219932

E-mail: dovre@stovax.com Internet: www.dovre.co.uk